

Brako

Digital Glass Break Detector



Installation Instructions

P/N 4720


The Brako is the ultimate answer false alarms free sensor. It catches sounds of breaking glass, which produce two sequential signals of different frequencies. The exclusive Brako Phased Frequency detection detects both shock signal and the strong signal of glass breakage creating a "false alarm free" glass break detector.

The Brako does not need to be on a window, thus providing volume protection and allowing protection of several windows with one detector.

FEATURES

- Shock and/or breakage selectable
- Analyzes two frequencies
- Unique signal analysis ignores environmental disturbances
- Memory LED
- ASIC based digital electronics
- Sensitivity adjustment
- New ultra compact design
- Flush mount installation (option)
- Outstanding detection range and reliability

FIG. 1 - MOUNTING



The detector offers flexible installation. It can be either ceiling mounted or wall mounted as shown in the above figure.

MOUNTING LOCATION (See FIG. 1)

- If heavy blinds or curtains cover the glass, you must locate the detector behind the blinds on the window frame or above it, otherwise the blinds might block the sound. Make sure to test the unit thoroughly for proper detection.
- Install the detector in a direct line of sight with the protected glass.
- Do not mount the unit in front of air ducts, or close to bells (measuring 0.5m (or larger) in diameter).
- For a few protected glasses in one room, locate the detector in optimal distance from them to achieve the best detection.

Note: For symmetrical cover of the detection area it is recommended to place the detector on the ceiling.

MOUNTING THE DETECTOR (FIG. 2)

1. Use the small screwdriver (supplied) to push the prong on top of the case to open it.
2. Snap out the detector PCB.
3. Insert the wires through the wiring hole (B).
4. Use the mounting holes (A) to mount the detector.
5. Connect the wires to the terminal. (See Terminal Connections)
6. Reinstall the detector PCB.
7. Close the case.

JUMPERS (FIG. 4)

- **JP1** - Shock / Glass selector for detection calibration.
- **JP2** - Memory LED control.
- **JP3** - Reduces the sensitivity of sound detection by 50%.

FIG. 2 - THE BACK COVER





FIG. 3 - TERMINAL BLOCK



TERMINAL BLOCK CONNECTIONS

Terminal 1 - Marked - (-12V)

Connect to negative 12V.

Terminal 2 - Marked + (+12V)

Connect to the positive voltage output of 9-16 Vdc source (usually from the alarm control unit)

Terminals 3 & 4 - Marked TAMPER

If a Tamper function is required connect these terminals to a 24 hour normally closed protective zone in the control unit. If the front cover of the detector is opened, an immediate alarm signal will be sent to the control unit.

Terminals 5 & 6 - Marked RELAY

These are the output relay contacts of the detector. Connect to the control at zone input.

THE CALIBRATION TOOL (*)

The Simulator/Tester & Calibration tool is especially designed to check phased frequency glass break detectors.

Since the detector will react to the high frequency breakage sound only when it comes sequentially after a low frequency SHOCK sound, this device is necessary to check the proper operation of the **Brako** without actually breaking the glass.

Manual mode:

In this mode, the Simulator will emit the high frequency sound of breaking glass for "Glass" adjustment.

Automatic mode:

In order to simulate breaking glass, place the Simulator on the surface of the protected glass, and gently hit it with your hand. The Simulator will then emit the sound of breaking glass. Be careful not to break the glass while testing the detector.

* It is recommended to use **Av-Gad** simulator

TESTING THE DETECTOR

First use the Simulator in manual mode to simulate the noise of glass breaking. Check that the Yellow LED is on. If it does not light, the sensitivity calibration is necessary (See Sound Calibration).

Carefully strike the glass with your hand or a padded object. If the Green LED does not light, adjust as sensitivity (See Shock Calibration).

Now use the Simulator in automatic mode and check that the red LED lights. If the Red LED is ON, your detector is working properly. Otherwise try adjusting the sound and shock setting until the Red LED lights.

GLASS BREAK ADJUSTMENT

To adjust the glass break setting (increase/decrease sensitivity) place the jumper JP1 according to the GLASS marking (connecting the middle pin with the upper pin) - (See Fig. 4) Green LED is constantly ON.

Now you can adjust the sensitivity by rotating the upper potentiometer (marked as GLASS CAL. - see Fig. 4).

Operate the Sound Break Simulator and rotate the potentiometer clock-wise to increase sensitivity, and opposite to decrease sensitivity until the Yellow and Red LED's are illuminating for each glass break sound. Remember that rotating the potentiometer will have no effect upon the settings if the middle pin of JP1 is not connected to the left pin.

Note

- When the jumper is set for GLASS adjustment, only the high frequency sound of breaking glass is detected.

SHOCK ADJUSTMENT

To adjust the shock setting (increase/decrease sensitivity) place the jumper JP1 according to the SHOCK marking (connecting the middle pin with the lower pin) - (See Fig. 4) Yellow LED is constantly ON.

Now you can adjust the sensitivity by rotating the lower potentiometer (marked as SHOCK CAL. - see Fig. 4).

Hit gently on the protected glass and rotate the potentiometer clock-wise to increase sensitivity, and opposite to decrease sensitivity until the Green and Red LED's are illuminating for each hit.

Remember that rotating the potentiometer will have no effect upon the settings if the middle pin of JP1 is not connected to the right pin.

Note

- When the jumper is set for SHOCK adjustment, only the low frequency of the shock signal prior to glass breakage is detected.

THE MEMORY FUNCTION

The alarm memory function allows the identification of an alerting detector out of multiple detectors connected to one (or the same) zone of the control panel.

To enable this function, set ON jumper JP2 (connected on both pins - See Fig. 4).

In case of an alarm, the Red LED will stay ON until memory function is reset.

To reset the memory function, switch OFF (disconnect) the voltage wire (+12V) from the Terminal Block for minimum 15 seconds then switch on (reconnect) voltage wire (+12V). (The control panel key ON/OFF can be used for this application if it controls the voltage (+12V)).

SENSITIVITY SETTING


For some installations you may find that Brako is too sensitive. Use jumper JP3 to decrease sensitivity to 50%.

JP3 OPEN - 100% sensitivity

JP3 CONNECTED - 50% sensitivity

FINAL TESTING

- Make sure to disconnect Jumper JP1. When the jumper is disconnected, the detector will detect both shock and sound frequencies.
- To ensure maximum protection against false alarms, activate any device in the area, which might automatically cycle pumps, generators, heating/air conditioning units, etc. If the cycling devices trigger an alarm, mount the unit in a different location.

FIG. 4 - PCB Layout**TECHNICAL SPECIFICATIONS**

Power Input	9 - 16 Vdc
Current Consumption	Standby: 22mA at 12Vdc Active: 25mA at 12Vdc
Detection Range	10m (33ft), Adjustable
Coverage	Omni Dirctional
Dimensions	70 x 40 x 16 mm
Mounting	Ceiling or Wall
Alarm Output Relay	N.C. 50mA/24Vdc with 27 Ohm in line resistor
Tamper Switch	N.C. 50mA 24Vdc with 10 Ohm in line resistor
Operating Temperature	- 20°C to 50°C (-4°F to 122°F)
Operating Humidity	95% max relative humidity non condensing
Storage Temperature	-30°C to 70°C (-22°F to 158°F)
Sensor	Condenser Microphone
RFI Protection	30V/m 10 -1000MHz
EMI Protection	50,000V electrical Interference from lightning

AV-GAD reserves the rights to change specifications without prior notice

AV-GAD LIMITED WARRANTY

(Av-Gad) warrants this product to be free from defects in materials and workmanship under normal use and service for a period of one year from the last day of the week and year whose numbers are printed on the printed circuit board inside this product.

Av-Gad's obligation is limited to repairing or replacing this product, at its option, free of charge for materials or labor, if it is proved to be defective in materials or workmanship under normal use and service. Av-Gad shall have no obligation under this Limited Warranty or otherwise if the product is altered or improperly repaired or serviced by anyone other than Av-Gad.

There are no warranties, expressed or implied, of merchantability or fitness for a particular purpose or otherwise, which extend beyond the description on the face hereof. In no case shall Av-Gad be liable to anyone for any consequential or incidental damages for breach of this or any other warranty, expressed or implied, or upon any other basis of liability whatsoever, even if the loss or damage is caused by Av-Gad's own negligence or fault.

Av-Gad does not represent that this product can not be compromised or circumvented; that this product will prevent any person injury or property loss or damage by burglary, robbery, fire or otherwise; or that this product will in all cases provide adequate warning or protection. Purchaser understands that a properly installed and maintained product can only reduce the risk of burglary, robbery or other events occurring without providing an alarm, but it is not insurance or a guarantee that such will not occur or that there will be no personal injury or property loss or damage as a result. Consequently, Av-Gad shall have no liability for any personal injury; property damage or any other loss based on claim that this product failed to give any warning. However, if Av-Gad is held liable, whether directly or indirectly, for any loss or damage arising under this limited warranty or otherwise, regardless of cause or origin, Av-Gad's maximum liability shall not in any case exceed the purchase price of this product, which shall be the complete and exclusive remedy against Av-Gad.

WIRE SIZE REQUIREMENTS

Use #22 AWG (0.5mm) diameter or larger wires. Use the following table to determine required wire gauge (diameter) and length of wire between the detector and the control panel.

Wire Length	m	200	300	400	800
Wire Diameter	mm	.5	.75	1.0	1.5
Wire Length	ft	800	1200	2000	3400
Wire Gauge	#	22	20	18	16

Av-Gad Systems Ltd.

ISRAEL: 84, Ben-Zvi Road, Tel-Aviv 68104
Tel: 972-3-681 67 67
Fax: 972-3-683 55 05
E-mail: support@av-gad.com
www.av-gad.com

These instructions supersede all previous issues prior to June 2002.

Item 4720 version 01, June 2002